



- (A) CRANK CASE VENTILATION
- (B) UNIVERSAL BRACKET
- (C) NEW PLACEMENT FOR ALTERNATOR

SCALE 1:5
 THIS DRAWING SPECIFIES THE "SOLAS" INTERFACE.
 OTHER ENGINE DIMENSIONS SEE THE TYPE DRAWING.

<small> In order to ensure the correct use of the engine, the user must refer to the Volvo Penta manual. The manual is available in English, French, German, Italian, Japanese, Korean, Spanish, Swedish, and Chinese. For more information, please contact your local Volvo Penta distributor. </small>	SYMBOLS, DIMENSIONS AND OTHER INFORMATION DIMENSIONS IN PARENTHESIS ARE IN INCHES	
	ENGINE DIMENSIONS SOLAS D4/106	
VOLVO PENTA		DISPOSITION DRAWING 35521518
03		11

35521518-03 - Зарпучено c www.volvopenta.com 26.06.2014 6:59:17