



- (A) CRANK CASE VENTILATION
- (B) UNIVERSAL BRACKET
- (C) NEW PLACEMENT FOR ALTERNATOR

SCALE 1:5
 THIS DRAWING SPECIFIES THE "SOLAS" INTERFACE.
 OTHER ENGINE DIMENSIONS SEE THE TYPE DRAWING.

| | | |
|--|--|--|
| <small> In every dimension and drawing the number shall be given in millimeters unless otherwise specified in a drawing. All dimensions shall be given in millimeters. If a dimension is given in inches and millimeters, the inch dimension shall be given in parentheses after the millimeter dimension. </small> | SYMBOLS, DIMENSIONS AND OTHER DATA ENGINE DIMENSIONS SOLAS D4/06 | |
| | VOLVO PENTA | |

35521518-03 - Заручено с www.volvopenta.com 26.06.2014 7:04:00